

Press and hold small push button on harness board for **5 seconds** to enter program mode

A ↑	1 ,...;	2 ABC
B ↓	3 DEF	4 GHI
C →	5 JKL	6 MNO
D ←	7 PQRS	8 TUV
E	9 WXYZ	10 B – Blank BS – Backspace EOL – End of Line
F	11	12
G	13	14 Enter